


## **MULTIBECK®** USING WITH BROILERS



## **BEFORE CHICKS ARRIVE**

- To set the feed level : turn the upper pan 3/4 to1 turn from lower pan
- Turn on the feed line
- Distribute the feed by slightly shaking the feeder








## **BROILER'S BACK = LEVEL WITH LOWER PAN EDGE**

The neck of the bird should be slightly outstretched when



www.le-roy.fr